

Computer Graphics

by Ruen-Rone Lee
ICL/ITRI



Wrap up from last week

◆ Modeling

- 3D Reconstruction
- Solid modeling
- Curve and Surface modeling



Anti-aliasing



***Super-sampling
Multi-sampling
Post Processing***



What is Anti-Aliasing


What is Aliasing

◆ Staircase-edges (jaggies)




What is Aliasing

◆ Polygon Popping




Major Issues

- ◆ Smooth the jaggies along the edges




Aliased lines




Anti-aliased lines

Major Issues

- ◆ Smooth the jaggies along the edges



Aliased triangles



Anti-aliased triangles

Why Anti-Aliasing ?

- ◆ **Not enough samples in computer-generated image, results in:**
 - Jagged, crawling edge
 - Polygon popping, flickering
- ◆ **Human eyes are sensitive to discontinuity**
- ◆ **Anti-Aliasing is required for better image quality**




Why Anti-Aliasing ?

◆ **Fake resolution**


- **Look smooth using anti-aliasing technique under lower resolution**

◆ **Higher resolution**

- **Greater than 200ppi (pixel per inch)**
- **Apple Retina Display (eg. 1440x900 → 2880x1800)**




Conventional LCD Display



Retina Display

Accumulation Buffer

- ◆ Using jittering technique to draw jittered triangle into different buffers and then accumulate the buffer by some weighting into the final display buffer.



Super-Sampling

- ◆ **How to solve aliasing**
 - Taking more samples
 - Extra samples instead of one single central sample per-pixel
 - Increase the density of image information
- ◆ **Two types of super-sampling anti-aliasing**
 - Ordered Grid Super-Sampling
 - Rotated Grid Super-Sampling



Super-Sampling

◆ **Advantage**

- **Transparent to the user**
- **Can handle correctly with interpenetrating objects**


◆ **Disadvantage**

- **Need more memory to store data**
- **Need more memory bandwidth to read/write Z and color data**
- **Longer rasterization time**



Super-Sampling


- ◆ Use more samples per screen grid cell, and blend with assigned weights



Super-Sampling


◆ **Ordered Grid Super-Sampling**

- **Sub-sample grid is parallel and aligned to the horizontal and vertical axis**




Super-Sampling

◆ Ordered Grid Super Sampling




Super-Sampling

- ◆ **Rotated Grid Super-Sampling**
 - The sub-sample grid is shifted off of the axis




Super-Sampling

◆ Rotated Grid Super Sampling




Super-Sampling

- ◆ Reduce the number of samples



Ordered Grid Super Sampling

◆ An Implementation



Rotated Grid Super Sampling

◆ An Implementation




Image Quality (Near Horizontal)








Image Quality




(a)




(b)




(c)



(d)





(a)



(b)

Image Quality (45 degree)





(a)




(b)




(c)



(a)



(b)







(c)




(d)

Image Quality (45+ degree)




Comparison


2 sampled OGSS





2 sampled RGSS



4 sampled OGSS



Eye Sensitivity to Different Angles



Some Findings

- ◆ **Anti-aliasing improve the image quality, but always comes with performance cost.**
- ◆ **Higher resolution can only reduce the aliasing effect but not eliminate**
- ◆ **Typical rotating angle is about 20~30 degrees for RGSS**
- ◆ **RGSS is superior than OGSS**
 - **2-sampled RGSS \approx 4-sample OGSS**

Anti-Aliasing Result



Without Anti-asliasing



With Anti-asliasing

Anti-Aliasing Result



Non anti-aliasing



OGSS



RGSS

Anti-Aliasing Result



Non anti-aliasing




OGSS



RGSS


Multi-Sample AA (MSAA)

- ◆ Similar to super-sampling
- ◆ Sample texture once for all sub-samples in a pixel



MSAA

- ◆ Sample texture once for all sub-samples in a pixel




More than just SSAA and MSAA


- ◆ CSAA (Coverage Sampling AA)
- ◆ AMSAA (Adaptive MSAA)
- ◆ Transparency AA
- ◆ CFAA (Custom Filter AA)
- ◆ SMAA (Subpixel Morphological AA)
- ◆ FXAA (Fast Approximate AA)
- ◆ SRAA (Subpixel Reconstruction AA)
- ◆ MLAA (Morphological AA)
- ◆ TXAA (Temporal AA)
- ◆ ...

Coverage Sampling AA (CSAA)

- ◆ Decouple coverage samples from ordinary color samples




CSAA Mode	colorSamples value	coverageSamples value
8x	4	8
8xQ (Quality)	8	8
16x	4	16
16xQ (Quality)	8	16




Coverage Sampling AA (CSAA)

◆ Similar to Enhanced Quality AA (EQAA)



Adaptive AA and Transparency AA

- ◆ Solving texture aliasing with alpha transparency in texels




Adaptive AA and Transparency AA



Adaptive AA and Transparency AA



- ◆ Solving texture aliasing with alpha transparency in texels





Custom Filter AA (CFAA)





Custom Filter AA (CFAA)



Standard 8x MSAA
(Box Filter)





12x CFAA
Narrow Tent Filter



16x CFAA
Wide Tent Filter

Morphological AA (MLAA)

- ◆ Smooth out jaggies using post processing




Morphological AA (MLAA)



(e)




(f)



(g)

FXAA

◆ Fast Approximate AA (post processing)




No AA

4xMSAA

FXAA

FXAA


- ◆ Find all the edges and smooth the edges




Subpixel Reconstruction AA

← Similar Time →


← Similar Quality →



(a) $1\times$ Shading + Box (poor, fast)




(b) **NEW: $1\times$ Shading + SRAA** (good, fast)



(c) $16\times$ Shading + Box (good, slow)


Subpixel Reconstruction AA




(a) Vector Input




(b) 1x Shading



(c) 1x Shading + MLAA




(d) 1x Shading + New SRAA



(e) 16384x Shading Reference


Subpixel Reconstruction AA

- Shaded sample
- Edge
- Geometric sample



Temporal MSAA (TXAA)

- ◆ Use less samples to achieve higher samples results




Temporal MSAA (TXAA)



No AA



8x MSAA



TXAA

Temporal MSAA (TXAA)

Temporal MSAA (TXAA)

Q&A

